



WOOD GRAIN NZ

WOODTURNING



Supreme Haarlem Danish Oil: Quick Application Guide

Follow these steps for a professional, durable finish on your timber projects.

Step 1: Preparation

Sand: Work through grits from 80 up to 400–600 for the best result.

Clean: Ensure the wood is dry and dust-free. **Shake the oil well.

Note: Test first on oily woods like **Rimu or Totara.

Step 2: The First Coat

Apply: Wipe on liberally with a rag, following the grain.

Soak & Wipe: Let sit for 5–15 minutes, then wipe off (ALL) excess oil.

Dry: Wait 8-24 hours (approx. 20°C)

Step 3: Build & Finish (Coats 2, 3+)

Prep: Lightly rub the surface with 0000 synthetic steel wool (with the grain).

Apply: Apply a "flood coat" so the wood stays wet. If it drinks the oil, add more.

Wipe & Dry: After 5–15 minutes**, wipe off every bit of excess. Leaving excess will cause a tacky finish.

Repeat: Dry for 8-24 hours (approx. 20°C) before adding more coats for a deeper luster.

Safety & Tips

Temperature: Only apply if it is above 10°C.

Ventilation: Use in a well-ventilated space.

Fire Hazard: Rags can self-ignite. Lay rags flat to dry outside or soak in water before throwing them away.

Order online at: www.woodgrainnz.co.nz